

BMW 3-Series and Z4 (99-05) Includes 2006 325ci/330ci Coupe and Convertible models Haynes Online Manual.

## Inspection I - 30,000 miles (48,000 km) or 24 months, whichever comes first

Check the manual transmission fluid level (if equipped) (Section 2) Replace the engine oil and filter (Section 3) Reset service interval display (Section 4) Check all underhood components and hoses for fluid leaks (Section 5) Check the condition of the drivebelts and replace if necessary (Section 6) Check the condition of the steering and suspension components (Section 7) Check the front brake pad thickness (Section 8) Check the rear brake pad thickness (Section 9) Check the operation of the parking brake (Section 10) Check the exhaust system and mountings (Section 11) Check the condition and operation of the seat belts (Section 12) Lubricate all hinges and locks (Section 13) Replace the cabin air filter (Section 14) Check the headlight beam alignment (Section 15) Check the operation of the windscreen/headlight washer system(s) (as applicable) (Section 16) Check the engine management system (Section 17) Carry out a road test (Section 18)

© 2024 Haynes Manuals, Inc. Contact us