

BMW 3-Series (92-98) & Z3 (96-98) Haynes Online Manual

10 Brake hoses and lines - inspection

1 Raise the vehicle and place it securely on jackstands.

2 Inspect all flexible brake hoses. Verify that they're in good condition and correctly routed. If a hose is cracked or otherwise damaged, replace it (see Chapter 9). And make sure that the brake hose-to-brake line fittings are tight and free of corrosion.

3 Inspect all rigid metal <u>brake lines</u>. Verify that they're not corroded, dented or otherwise damaged. Replace worn or damaged lines (see <u>Chapter 9</u>).

© 2024 Haynes Manuals, Inc. Contact us