

BMW 3-Series (92-98) & Z3 (96-98) Haynes Online Manual

## 8 Timing chain sprockets and tensioner - removal and installation

## **Camshaft sprockets and tensioner**

1 Removal and installation are described as part of the timing chain removal procedure in Section 7.

## **Crankshaft sprocket**

- 2 Remove the timing chain (see Section 7).
- 3 Slide the sprocket from the crankshaft, and recover the Woodruff key if it is loose.
- 4 Installation is a reversal of removal, but install the timing chain (see Section 7).

## **Idler sprocket**

- 5 Remove the timing chain (see Section 7).
- 6 Unbolt the sprocket from the timing chain housing.
- 7 Installation is a reversal of removal, noting the following points.
  - A. Ensure that the sprocket is installed the correct way the greater projecting boss on the sprocket should be facing the timing chain housing.
  - B. Ensure that the washer is in place under the securing bolt.
  - C. Install the timing chain (see <u>Section 7</u>).

© 2024 Haynes Manuals, Inc. Contact us