

BMW 3-Series (92-98) & Z3 (96-98) Haynes Online Manual

2 Air cleaner assembly - removal and installation

Removal

- 1 Remove the airflow meter and air cleaner cover assembly (see Section 12).
- 2 Loosen the two nuts securing the <u>air cleaner</u> casing to the mounting bracket, then pull the casing upwards, and unclip the intake duct from the front body panel (see illustration).

2.2 Removing the air cleaner assembly



Installation

3 Installation is a reversal of removal, but ensure that the lower mounting engages with the plastic lug on the body, and install the airflow meter (see Section 12).

© 2024 Haynes Manuals, Inc. Contact us