

BMW 3-Series and Z4 (99-05) Includes 2006 325ci/330ci Coupe and Convertible models Haynes Online Manual.

2 Air cleaner assembly - removal and installation

Removal

- 1 Release the engine wiring harness from the retaining bracket on the air cleaner housing.
- 2 Release the clips and disconnect the intake hose from the top section of the housing.
- 3 Unscrew the two retaining bolts and remove the <u>air cleaner</u> housing from the engine compartment, disengaging it from the inlet ducting as it is withdrawn (see illustration).

2.3 Air cleaner housing mounting bolts (2004 shown, others similar)



Installation

4 Installation is a reverse of removal, but ensure that the lower mounting engages with the plastic lug on the body (see illustration), and where a rubber seal is installed between the intake hose and the housing, apply a little acid-free grease to the seal to ease installation.

2.4 The plastic bracket on the inner fender used for mounting the air cleaner housing



© 2024 Haynes Manuals, Inc. Contact us