

BMW 3-Series (92-98) & Z3 (96-98) Haynes Online Manual

21 Cruise control system components (3-Series models) - removal and installation

Electronic control module (ECM)

- 1 Remove the glovebox (see <u>Chapter 11</u>).
- 2 Unclip the lower dash panel and remove it from underneath the glovebox aperture.
- 3 Release the retaining clip, withdraw the ECM then release the retaining clip and disconnect wiring connector.
- 4 Installation is the reverse of removal.

Cruise control actuator

- 5 The cruise control actuator is located in the engine compartment.
- 6 Disconnect the wiring connector from the actuator.
- 7 Remove the outer cable retaining clip, then release the cable from the bracket and detach the inner cable from the actuator.
- 8 Remove the retaining nuts and remove the actuator from the engine compartment.
- 9 Installation is the reverse of removal.

System operating switch

10 Refer to Section 4.

Brake and clutch pedal switches

11 Refer to Chapter 8 (clutch pedal switch) or Chapter 9 (brake switch).

© 2024 Haynes Manuals, Inc. Contact us