

BMW 3-Series (92-98) & Z3 (96-98) Haynes Online Manual

# 13 Clock/multi-information display/on-board trip computer - removal and installation

### 3-Series models

#### Removal

- 1 Disconnect the battery negative <u>terminal</u>. Caution: If the stereo in your vehicle is equipped with an anti-theft system, make sure you have the correct activation code before disconnecting the battery.
- 2 Insert a <u>feeler gauge</u> (approximately 0.004-inch thick) in between the base of the clock/multi-information display and mounting.
- 3 Carefully release the retaining clip then slide the clock/multi-information display unit out from the dash center panel and remove it, disconnecting its wiring connectors as they become accessible (see illustrations).

13.3a Unclip and remove the clock as shown . . .



13.3b . . . and disconnect it from the wiring connector (3-Series models)



#### Installation

4 Installation is the reverse of removal.

## Z3 models (clock/on-board trip computer)

5 Pry the clock/on-board trip computer from the center console (see illustration), pull out the unit, unplug the electrical connector and remove the unit.

13.5 To remove the clock/on-board trip computer from the center console on a Z3 model, simply pry it out and unplug it



6 Installation is the reverse of removal.

© 2024 Haynes Manuals, Inc. Contact us