

BMW 3-Series 320i & 320xi (12-14), 325i, 325xi, 330i & 330xi (06) & 328i & 328xi (07-14) Haynes Online Manual

6 Fastener and trim removal

- 1 There is a variety of plastic fasteners used to hold trim panels, splash shields and other parts in place in addition to typical screws, nuts and bolts. Once you are familiar with them, they can usually be removed without too much difficulty.
- 2 The proper tools and approach can prevent added time and expense to a project by minimizing the number of broken fasteners and/or parts.
- 3 The following illustration shows various types of fasteners that are typically used on most vehicles and how to remove and install them (see illustration). Replacement fasteners are commonly found at most auto parts stores, if necessary.
- 4 Trim panels are typically made of plastic and their flexibility can help during removal. The key to their removal is to use a tool to pry the panel near its retainers to release it without damaging surrounding areas or breaking-off any retainers. The retainers will usually snap out of their designated slot or hole after force is applied to them. Stiff plastic tools designed for prying on trim panels are available at most auto parts stores (see illustration). Tools that are tapered and wrapped in protective tape, such as a screwdriver or small pry tool, are also very effective when used with care.





 $\ensuremath{\texttt{©}}$ 2024 Haynes Manuals, Inc. Contact us