

BMW 3-Series and Z4 (99-05) Includes 2006 325ci/330ci Coupe and Convertible models Haynes Online Manual.

4 Fuel expansion tank - removal and installation

Warning:

Refer to the Warning in Section 1 before proceeding.

- 1 Loosen the right-rear wheel <u>lug nuts</u>, raise the right-hand rear side of the vehicle and support it securely on jackstands. Remove the right-rear wheel.
- 2 Remove the plastic nuts/screws/expansion rivets and remove the liner in the right-rear wheel well (see <u>Chapter 12</u>).
- 3 Remove the retaining nut, disconnect the lower hose, and pull the bottom of the tank forward (see illustration) .

4.3 Remove the expansion tank retaining nut



- 4 Note their installed positions, then loosen the clamps and disconnect the remaining two breather hoses from the tank. Remove the tank.
- 5 Installation is a reversal of removal.

© 2024 Haynes Manuals, Inc. Contact us