



Haynes
shows you how

BMW 3-Series (92-98) & Z3 (96-98) Haynes Online Manual

11 Brake pedal - removal and installation

Removal

- 1 Disconnect the battery negative terminal.
- 2 Remove the brake light switch (see [Section 18](#)).
- 3 Using a pair of pliers, carefully unhook the return spring from the brake pedal.
- 4 Slide off the retaining clip and remove the clevis pin securing the brake pedal to the brake booster pushrod.
- 5 Slide off the pedal pivot pin retaining clip and remove the pedal from the pivot.
- 6 Carefully clean and inspect all components, replacing any that are worn or damaged.

Installation

- 7 Installation is the reverse of removal. Apply a smear of multi-purpose grease to the pedal pivot and clevis pin.

© 2024 Haynes Manuals, Inc. Contact us