

BMW 3-Series and Z4 (99-05) Includes 2006 325ci/330ci Coupe and Convertible models Haynes Online Manual.

14 Horn(s) - removal and installation

- 1 The horns are located behind the left- and right-hand ends of the front bumper.
- 2 To gain access to the horn(s) from below, apply the parking brake then jack up the front of the vehicle and support it on jackstands. Remove the retaining screws and remove the lower front section of the wheel arch liner. Unclip and remove the <u>brake disc</u> cooling duct.
- 3 Remove the retaining nut/bolt and remove the horn, disconnecting its wiring connectors as they become accessible.
- 4 Installation is the reverse of removal.

© 2024 Haynes Manuals, Inc. Contact us