

BMW 3-Series and Z4 (99-05) Includes 2006 325ci/330ci Coupe and Convertible models Haynes Online Manual.

## 6 Bumper (front) - removal and installation

- 1 Raise the vehicle and support it securely on jackstands.
- 2 Remove the fog light trim panels. Release the retaining clips and pull the fog light trims forward and away from the bumper (see illustration).

6.2 Push the 'fins' of the trim down, release the clips and pull the fog light trims out



3 Remove the mounting screws and the right and left side trim pieces (see illustration) .

6.3 Remove the two screws at the bumper lower edge



4 Remove the retaining screws from the fender splash shield that connect to the bumper assembly (see illustration) .

## 6.4 Remove the screw securing the bumper to the wheel well liner



5 Remove the front bumper cover mounting screws (see illustration) .

## 6.5 Location of the bumper cover fasteners on the left side of the vehicle



- 6 Remove the bumper cover forwards and away from the vehicle.
- 7 Remove the bumper mounting bolts and move the bumper slightly away from vehicle.
- 8 Note their installed locations, and disconnect the various wiring connectors.
- 9 Remove the bumper from the vehicle by sliding the bumper off side support brackets.
- 10 Installation is a reverse of the removal procedure, ensuring that the bumper mounting nuts and screws are securely tightened.

 $\ensuremath{\text{@}}$  2024 Haynes Manuals, Inc. Contact us