

BMW 3-Series and Z4 (99-05) Includes 2006 325ci/330ci Coupe and Convertible models Haynes Online Manual.

## 11 Rain sensor - removal and installation

1 The rain <u>sensor</u> is incorporated into the front face of the interior mirror mounting base. Press up on the lower end of the mounting trim, and press the two halves of the mounting trim apart at the base, and release the trim retaining clips (see illustration).

## 11.1 Press the two halves of the trim apart



- 2 With the trim removed, disconnect the sensor wiring connector
- 3 Pull out the two sensor retaining clips, and pull the sensor to the rear (see illustration) .

11.3 Pull out the clip on each side and remove the sensor



4 Installation is the reverse of removal.

© 2024 Haynes Manuals, Inc. Contact us