

BMW 3-Series and Z4 (99-05) Includes 2006 325ci/330ci Coupe and Convertible models Haynes Online Manual.

7 Knock sensor - removal and installation

Removal

- 1 Two knock sensors are used, bolted to the left-hand side of the <u>cylinder block</u>. One sensor detects knocking in Numbers 1 to 3 cylinders, and the other sensor detects knocking in Numbers 4 to 6 cylinders.
- 2 Disconnect the cable from the negative <u>terminal</u> of the battery (see <u>Section 1</u>).
- 3 Remove the intake manifold (see Chapter 4).
- 4 Locate the <u>sensor</u> connector bracket which is located beneath the idle speed control valve. **Warning**: *If both knock sensors are to be removed, mark the wiring connectors to ensure correct installation. Incorrect reconnection may result in engine damage.*
- 5 Unclip the connector from the retaining clip, and disconnect the sensor wiring connector(s).
- 6 Unscrew the retaining bolt and remove the knock <u>sensor</u>, noting the routing of the wiring. The sensor for cylinders 1 to 3 is located beneath the temperature sensors in the <u>cylinder head</u> (see illustration). The <u>sensor</u> for cylinders 4 to 6 is located to the rear of the sensor wiring connector bracket.

7.6 The knock sensors are located just below the cylinder head on the engine block



Installation

7 Commence installation by thoroughly cleaning the mating faces of the sensor and the cylinder block.

8 Install the <u>sensor</u> to the <u>cylinder block</u>, tightening the securing bolt to the torque listed in <u>this Chapter's</u> <u>Specifications</u>.

9 Route the wiring as noted before removal, then reconnect the connector(s), and clip the connector to the bracket, ensuring that the connectors are positioned as noted before removal. Warning: Ensure that the wiring connectors are correctly connected as noted before removal. If the connectors are incorrectly connected mixed up), engine damage may result.

10 Install the intake manifold (see Chapter 4).

© 2024 Haynes Manuals, Inc. Contact us