

BMW 3-Series (92-98) & Z3 (96-98) Haynes Online Manual

# 2 Front hub assembly - removal and installation

## Removal

#### Note:

The hub assembly should not be removed unless it is to be replaced. The hub bearing inner race is a pressfit on the steering knuckle, and removal of the hub will almost certainly damaged the bearings; the manufacturer states that the hub assembly must be replaced whenever it is removed. A new hub nut and grease cap will also be required on installation.

- 1 Remove the front <u>brake disc</u> (see <u>Chapter 9</u>). On models with ABS, also remove the front wheel <u>sensor</u>.
- 2 Tap the grease cap out from the center of the hub (see illustration) .

# 2.2 Tap out the grease cap from the center of the hub



3 Using a hammer and chisel, tap up the staking securing the hub retaining nut in position, then loosen and remove the nut (see illustration).

2.3 Using a hammer and pointed-nosed chisel, tap out the hub nut staking



4 Attach a suitable puller to the hub assembly and draw the assembly off the <u>steering knuckle</u>. If the bearing inner race remains on the steering knuckle, a knife-edge type puller will be required to remove it (see illustration). Note that the hub bearings are not available separately - the hub must be replaced as a complete assembly.

2.4 If the hub bearing inner race remains on the steering knuckle, use a puller to get it off



5 Inspect the <u>steering knuckle</u> shaft for signs of damage, and replace it if necessary (see <u>Section 3</u>). If required, remove the retaining screws and remove the disc guard from the <u>steering knuckle</u>.

### Installation

6 Where removed, install the disc guard to the steering knuckle, and securely tighten its retaining screws.

7 Ensure the dust cover is correctly installed on the rear of the hub assembly, and locate the hub on the <u>steering knuckle</u>. Tap or press the hub assembly fully onto the steering knuckle shaft using a tubular spacer which bears only on the bearing inner race (see illustration).

2.7 Tap the hub assembly into position using a socket which bears only on the inner race of the new bearing



- 8 Screw the new hub nut onto the <u>steering knuckle</u>. Tighten the nut to the specified torque, and secure it in position by staking it firmly into the knuckle groove using a hammer and punch.
- 9 Check that the hub rotates freely, and press the new grease cap into the hub center.
- 10 Install the brake disc (see Chapter 9). Where necessary, also install the ABS wheel sensor.

© 2024 Haynes Manuals, Inc. Contact us