

BMW 3-Series 320i & 320xi (12-14), 325i, 325xi, 330i & 330xi (06) & 328i & 328xi (07-14) Haynes Online Manual

## 23 Radiator grille - removal and installation

- 1 Open the hood.
- 2 Remove the fasteners securing the air duct to the top of the radiator (see illustration 9.3) .
- 3 Carefully remove the sealing strip.
- 4 Reach through the openings to access the back of the radiator to release the clips securing the grille.
- 5 Take care not to scratch the surrounding paint on the front bumper cover when removing/installing the grille. **Caution**: *Wear gloves when reaching through the openings.*
- 6 Installation is the reverse of removal.

© 2024 Haynes Manuals, Inc. Contact us